



CERTSWARRIOR

NFPA CFPS

Certified Fire Protection Specialist (CFPS)

Questions&AnswersPDF

ForMoreInformation:

<https://www.certswarrior.com/>

Features:

- 90DaysFreeUpdates
- 30DaysMoneyBackGuarantee
- InstantDownloadOncePurchased
- 24/7OnlineChat Support
- ItsLatestVersion

Visit us at: <https://www.certswarrior.com/exam/cfps>

Latest Version: 7.0

Question: 1

When evaluating dipping and coating processes, flammable liquid vapors are usually.

- A. denser than air, therefore, flow to high points.
- B. lighter than air, therefore, flow to low points.
- C. denser than air, therefore, flow to low points.
- D. lighter than air, therefore, flow to high points.

Answer: C

Explanation:

4.3* Locations Below Grade.

Dipping and coating processes shall not be located below the surrounding grade level in cases where flammable vapors that are heavier (denser) than air cannot be captured and directed to the outside of the building.

<http://hamyarenergy.com/static/fckimages/files/NFPA/Hamyar%20Energy%20NFPA%2034%20-%202007.pdf>

Question: 2

Pre-incident planning for industrial and municipal emergency response includes all of the following data components. EXCEPT

- A. Interior finishes
- B. Building construction
- C. Site considerations
- D. occupancy

Answer: A

Question: 3

Temporary storage of more than 60 gal (227 L) of Class I and Class II liquids should be low for from buildings under construction?

- A. At least 30 ft (9 m)
- B. At least 40 ft (12 m)
- C. At least 50 ft (15 m)

D. At least 60 ft (18 m)

Answer: C

Explanation:

16.2.3.1 Storage:

„h Storage of flammable and combustible liquids shall be in accordance with Chapter 66, unless otherwise modified by

16.2.3.

„h Storage of Class I and Class II liquids shall not exceed 60 gal (227 L) within 50 ft (15m) of the structure.

„h Storage area shall be kept free of weeds, debris, and combustible materials not necessary to the storage.

„h Open flames and smoking shall not be permitted in flammable and combustible liquids storage areas.

„h Such storages areas shall be appropriate posted as „no smoking“ areas.

„h Storage areas shall be appropriately posted with markings in accordance with NFPS 704, Standard System for the

identification of Hazards of Materials for Emergency Response.

Question: 4

NFPA 220 identifies which of the following as a construction type in which the structural elements are entirely of noncombustible or limited combustible materials permitted by the code and protected to have some degree of fire resistance for one hour?

A. Type II (222)

B. Type II (111)

C. Type III (211)

D. Type III (200)

Answer: A

Explanation:

Type I & Type II (222) are:

„h Noncombustible

„h Equivalent for compliance

Fire Resistance of Building Elements in Accordance with NFPA 220										
	Type I		Type II			Type III		Type IV	Type V	
	443	332	222	111	000	211	204	2HH	111	000
EXTERIOR BEARING WALLS										
Supporting more than one floor, columns or other bearing walls	4	3	2	1	0 ¹	2	2	2	1	0 ¹
Supporting one floor only	4	3	2	1	0 ¹	2	2	2	1	0 ¹
Supporting a roof only	4	3	1	1	0 ¹	2	2	2	1	0 ¹
INTERIOR BEARING WALLS										
Supporting more than one floor, columns or other bearing walls	4	3	2	1	0	1	0	2	1	0
Supporting one floor only	3	2	2	1	0	1	0	1	1	0
Supporting a roof only	3	2	1	1	0	1	0	1	1	0
COLUMNS										
Supporting more than one floor, bearing walls or other columns	4	3	2	1	0	1	0	H ²	1	0
Supporting one floor only	3	2	2	1	0	1	0	H ²	1	0
Supporting a roof only	3	2	1	1	0	1	0	H ²	1	0
BEAMS, GIRDERS, TRUSSES & ARCHES										
Supporting more than one floor, bearing walls or other columns	4	3	2	1	0	1	0	H ²	1	0
Supporting one floor only	3	2	2	1	0	1	0	H ²	1	0
Supporting a roof only	3	2	1	1	0	1	0	H ²	1	0
FLOOR CONSTRUCTION										
	3	2	2	1	0	1	0	H ²	1	0
ROOF CONSTRUCTION										
	2	1½	1	1	0	1	0	H ²	1	0
EXTERIOR NONBEARING WALLS³										
	0 ¹	0 ¹	0 ¹	0 ¹	0 ¹	0 ¹	0	0 ¹	0 ¹	0 ¹

¹ Those members listed that are permitted to be of approved combustible material.

² Requirements for fire resistance of exterior walls, the provision of spandrel wall sections, and the limitations or protection of wall openings are not related to construction type. They need to be specified in other standards and codes, where appropriate, and may be required in addition to the requirements of the standard for the construction type.

³ "H" indicates heavy timber members.

⁴ Exterior nonbearing walls meeting the conditions of acceptance of NFPA 285, Standard Method of Test for the Evaluation of Flammability Characteristics of Exterior Non-Load-Bearing Wall Assemblies Containing Combustible Components Using the Intermediate-Scale Multistory Test Apparatus, shall be permitted to be used.

Question: 5

The means of escape in lodging or rooming houses is defines as:

- A. A way out of a building that does not conform to the definition of means of egress, but does provide a safe way out
- B. A clear path of travel, which can be both vertical and/or horizontal, to means of egress leading to a public way or street
- C. An unusual archaic pathway that allows occupants to reach a protected, fire-rated stairwell, smoke tower, or exit door
- D. A convoluted or confusing pathway in a building designed and built before the adoption of building codes

Answer: A

Question: 6

When designing deflectors, the minimum water flow pressure needed to develop a reasonable spray pattern is:

- A. 4 psi (28 kPa)
B. 5 psi (34 kPa)
C. 6 psi (41 kPa)
D. 7 psi (48 kPa)

Answer: D

Explanation:




FIGURE 15.4 Some Modifications of the Common Link and Lower Construction: (a) General FPOD Quasipod, (b) Harada Model (2), and (c) Freestyle Type S

Deflector Design

Attached to the frame of the controller is a detector and control system that measures the amount of water in a channel and corrects for a spillage, designed to cover or protect a certain area. The amount of water discharged depends on the flowing water in the gutter and the size of the spillable surface. A flowing stream of 7 mm (0.28 in.) is provided by a constant flow meter (hardware) and a variable spillage plate. At this position, a spillage having a nominal flow rate of 0.22 m³/s (0.008 cfs) is 2.6 m (8.5 ft) in the main. $K_{sp} = 80$ will discharge approximately 17 mm (0.67 in.) (See Spillage Spreads with Different Orifice Sizes in this chapter for the definition of K_{sp}). At the same 7 mm (0.28 in.) position, $K_{sp} = 100$ will discharge approximately 21 mm (0.83 in.) (See Spillage Spreads for the quantity of water discharged at various spill plate sizes.)

In order to have over the maximum dynamic pressure at openings that are distant from the point of water supply, specially designed water supply systems are operating continuously. Water supply pressure in the range of 30 to 100 psi (210 to 690 kPa) are economically provided. Hydraulically calculated systems are designed around the economic available static supply volume and pressure.

The construction of water from a spring here is expected to be archaic, particularly since springs from areas adjacent the spring point, and the rounded edges of the diffusion create a "lapping" effect. A common pit of the flow pattern is the "lapping" effect. A common pit of the flow pattern is the "lapping" effect. A common pit of the flow pattern is the "lapping" effect.

Because the distribution of *s* varies from spintronics to spintronic phenomena, the scaling laboratories have fairly broad requirements for *s*. For example, the scaling laboratory requires χ^2 statistics for example. Undergraduate Laboratories can do it requires a variable and to "logarithm" the spintronics pattern. For a spintronics with an outlier of $K = 0.6$, $(K_0 - 0.6)/K_0 = 0.4$, $(K_0 - 1)/K_0 = 0.4$, and $(K_0 - 1.6)/K_0 = 0.4$ (the outlier) is not permitted outside a 1.6 (1.9) or decrease due to a fractional phase of 0.7 (0.7) up before the spintronics value (depending on non-zero pressure). It separates "logarithmic" distributions.




FIGURE 15.5 Water Discharge Rates of Typical Farmstead K₁ = 0.05, K₂ = 0.05, and K₃ = 0.05. Automatic Backflow

test checks **flexibility** of fire flooring against **so-called** burn tests where with their overlapping **crisp** patterns, Factory Mutual Research Corporation's (FMRC) applies an additional step: instead of **burn** test, which tests if **fire** area could be between two adjacent sections.

TEMPERATURE RATINGS OF AUTOMATIC SPRINKLERS

Automatic spin-downs have various temperature settings that are based on standardised tests in which a spin-down is increased in a liquid and the temperature of the liquid is raised very slowly until the spin-down operates (Table 10.1).

The temperature rating of all flexible-duct-manufactured automatic sprinklers is stamped on the wettest link. For each sprinkler, the temperature rating must be stamped in (or on) some visible part. Color coding can also used. See glass bulbs and fire ratings on page 10-13 for more information.

The recent drastic increase in room temperature is, in fact, due to both heat and fresh air stream openings. The *air* cause is due to the fact that the air is simply coming from the actual ceiling plate. The reason for this is that the air is actually coming from the ceiling plate. The reason for this is that the air is actually coming from the ceiling plate. The reason for this is that the air is actually coming from the ceiling plate.

The general rule of not using operations of ordinary ≥ 20 to 40°F (1 to 22°C) temperature ruling where temperatures exceed 100°F (38°C) is necessary to provide a margin of safety. General practice requiring the use of automatic operations at higher than the ordinary ruling gives us Tables IV and IV A.

Question: 7

What is the maximum size for solid particles capable of passing through a U.S. 40 standard sieve to be classified as dust?

- A. 0.016 in. (390 fgm)
B. 0.017 in. (420 fgm)
C. 0.018 in. (450 fgm)
D. 0.019 in. (480 fgm)

Answer: B

Question: 8

Heat flow from the flame to the burning fuel of a small pool fire is mostly due to:

- A. Convective heat transfer
- B. Conduction heat rise
- C. Conduction heat transfer
- D. Convective heat loss

Answer: A

Question: 9

Fire alarm wire failure can be classified as:

- I) Conductor breakage
- II) Short circuits
- III) Insulation loss
- IV) Trouble signals

- A. I
- B. II
- C. I and III
- D. II and IV

Answer: D

Question: 10

What special storage precautions are required for zirconium castings?

- A. Store in containers with 25 percent water by volume
- B. Store in fire-resistant construction with explosion vents
- C. Store in vessels with an inert atmosphere
- D. There are no special storage requirements

Answer: B

Explanation:

Storage and Handling

Special storage precautions are not required for zirconium castings because of the very high temperatures massive pieces of the metal can withstand without igniting. Zirconium powder, in contrast, is highly combustible; consequently, it is customarily stored and shipped in 1 gal (3.8 L) containers with at least 25 percent water by volume. For specific details, refer to NFPA 484.

Zirconium powder storerooms should be of fire-resistant construction equipped with explosion vents. Cans should be separated from one another to minimize the possibility of a fire in one can spreading to others and to permit checking of the cans periodically for corrosion. Some manufacturers of zirconium have established the practice of disposing of cans containing powder that have been on the shelf for 6 months.



CERTSWARRIOR

FULL PRODUCT INCLUDES:

Money Back Guarantee



Instant Download after Purchase



90 Days Free Updates



PDF Format Digital Download



24/7 Live Chat Support



Latest Syllabus Updates



For More Information – Visit link below:

<https://www.certswarrior.com>

16 USD Discount Coupon Code: U89DY2AQ